


WINvote Demonstration Ballot

Arlington County, Virginia

Step 1: START

The Election Officer will activate the ballot for your use. When you step up to the Ballot Welcome Screen, touch the [TOUCH HERE TO START] block to begin voting your ballot.




Step 2: MAKE SELECTIONS

The offices and question for which you can vote will appear on the screen, one office or question at a time. The title bar of offices and questions for which you have not made a selection will be flashing.


Touch the name of your selection or the square next to the selection of your choice. A red X will appear in the square and your selection will be highlighted in red.

If you make a mistake or change your mind, touch the square or selection again to clear it, and then touch your new selection.

Make all your selections as described above. Touch the **NEXT** or **BACK** blocks at the bottom of the screen to move forward or backward to other offices or questions. You can vote for as many or as few offices as you like.




To make a write-in selection, touch the **WRITE-IN** block for the office. A keypad will appear. Type out the name of your write-in choice and touch **NEXT** to return to making other selections.




Step 3: REVIEW

Once you have viewed all offices or questions, the Summary screen will appear. It displays the choices you have made for each office or question. A flashing office or question indicates you have not made a selection. If you wish to make any changes, simply touch the question or office. You will be returned to the screen for that office or question.



Step 4: VOTE

After you review the Summary screen, touch **NEXT**, and the final **VOTE** screen will appear. Touch the large flashing **VOTE** block to cast your ballot.



Your ballot has been cast!

Thank you for voting on Arlington's WINvote system. If you have any questions, please ask any Election Officer for assistance.

